

Accessories



Auxiliary Contacts

Table B-6. Front Mount Auxiliary Contacts for Use with XTRM Mini Control Relays

Conventional thermal current, I _{th} Open (A)	Rated Operational Current AC-15 I _e (A)			Contact Configuration	Contact Sequence	Package Qty.	Screw Terminals	Spring Cage Terminals	Price ^①
	220V 230V 240V	380V 400V 415V	500V				catalogue Number	catalogue Number	
10	4	2	1.5	2NC		5	XTMCXFA02	—	
10	4	2	1.5	1NO-1NC		5	XTMCXFA11	XTMCXFAC11	
10	4	2	1.5	2NO		5	XTMCXFA20	—	
10	4	2	1.5	1NO _E -1NC _L		5	XTMCXFAL11 ^②	—	
10	4	2	1.5	4NC		5	XTMCXFA04	XTMCXFAC04	
10	4	2	1.5	1NO-3NC		5	XTMCXFA13	XTMCXFAC13	
10	4	2	1.5	2NO-2NC		5	XTMCXFA22	XTMCXFAC22	
10	4	2	1.5	3NO-1NC		5	XTMCXFA31	XTMCXFAC31	
10	4	2	1.5	4NO		5	XTMCXFA40	XTMCXFAC40	
10	4	2	1.5	1NO-1NC 1NO _E -1NC _L		5	XTMCXFAL22 ^②	XTMCXFCLC22 ^②	

^① Orders must be placed in multiples of package quantity listed.

^② 1 early-make contact (NO_E), 1 late-break contact (NC_L).

B