

Accessories

Auxiliary Contacts

Side-Mount Auxiliary Contacts



Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR... and XTPAXFA... trip indicating auxiliary contact.

Table 183. Side-Mount Auxiliary Contacts

Contact Configuration	Contact Sequence	Screw Terminals		Spring Cage Terminals		Price U.S. \$ ①	
		Pkg. Qty.	Catalog Number	Pkg. Qty.	Catalog Number		
1NO-1NC	 XTPAXSA11		1	XTPAXSA11	5	XTPAXSAC11	21.30
1NO-2NC	 XTPAXSA12		1	XTPAXSA12	—	—	33.25
2NO-1NC	 XTPAXSA21		1	XTPAXSA21	—	—	33.25

① Price listed is for a quantity of one (1). Orders must be placed in multiples of package quantity listed.

Front-Mount Auxiliary Contacts



Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

Table 184. Front-Mount Auxiliary Contacts

Contact Configuration	Contact Sequence	Screw Terminals		Spring Cage Terminals		Price U.S. \$ ②	
		Pkg. Qty.	Catalog Number	Pkg. Qty.	Catalog Number		
1NO-1NC	 XTPAXFA11		1	XTPAXFA11	—	—	20.30
1NO-0NC	 XTPAXFA10		1	XTPAXFA10	5	XTPAXFAC10	16.00
0NO-1NC	 XTPAXFAC01		—	—	5	XTPAXFAC01	16.00

② Price listed is for a quantity of one (1). Orders must be placed in multiples of package quantity listed.

Discount Symbol **1CD7**