

Push Buttons & Operator Interface - XB4 22 mm Die Cast Chrome Plated Selector Switches

Non-Illuminated Selector Switches ■▲



ZB4BD4



ZB4BJ3

| Shape of Head | Type of Operator | Number and Type of Positions | | Catalog Number | | |
|------------------------------------|--|------------------------------------|------------------------------|----------------------------------|--|--------|
| | Standard lever, black For colored lever add the following code to end of part number: 01 - white 03 - green 04 - red 05 - yellow 06 - blue (Example: ZB4BD204) | 2 - maintained | | ZB4BD2 | | |
| | | 2 - momentary from right to left | | ZB4BD4 | | |
| | | 3 - maintained | | ZB4BD3 | | |
| | | 3 - momentary to center | | ZB4BD5 | | |
| | | 3 - momentary from left to center | | ZB4BD7 | | |
| | | 3 - momentary from right to center | | ZB4BD8 | | |
| | | | Extended lever, black | 2 - maintained | | ZB4BJ2 |
| | | | | 2 - momentary from right to left | | ZB4BJ4 |
| 3 - maintained | | | | ZB4BJ3 | | |
| 3 - momentary to center | | | | ZB4BJ5 | | |
| 3 - momentary from left to center | | | | ZB4BJ7 | | |
| 3 - momentary from right to center | | | | ZB4BJ8 | | |

Non-Illuminated Key Switches



ZB4BG8

| Shape of Head | Type of Operator | Number and Type of Positions | | Catalog Number ● |
|---------------|----------------------|------------------------------------|----------------|------------------|
| | Key (No. 455) | 2 - maintained | | ZB4BG2 |
| | | | | ZB4BG4 |
| | | 2 - momentary from right to left | | ZB4BG6 |
| | | | 3 - maintained | |
| | | | | ZB4BG3 |
| | | | | ZB4BG5 |
| | | | | ZB4BG9 |
| | | | | ZB4BG09 |
| | | | | ZB4BG1 |
| | | 3 - momentary from left to center | | ZB4BG1 |
| | | 3 - momentary to center | | ZB4BG7 |
| | | 3 - momentary from right to center | | ZB4BG8 |
| | ZB4BG08 | | | |

The symbol indicates key withdrawal position(s).

- For actuation of outside contacts only.
- ▲ See selector switch sequence charts on page 56.
- Other key numbers:
 - key No. 421E: add the suffix 12 to the reference.
 - key No. 458A: add the suffix 10 to the reference.
 - key No. 520E: add the suffix 14 to the reference.
 - key No. 3131A: add the suffix 20 to the reference.

Example:

The catalog number for a head with key No. 421E for a 2 position maintained, lockable selector switch, with key withdrawal from the left-hand position, becomes: ZB4BG212.