

**speco technologies™**

# VM-5LCD

## OSD Adjustment

1. Press the POWER ON/OFF button on the monitor to turn on the power.
2. Press MENU button on the monitor Keep 3-5secs or remote unit to activate the OSD functions shown on the LCD screen and press again to select the adjustment items as below.

VOLUME  
CONTRAST  
BRIGHTNESS  
COLOR  
TINT  
U/D NORM/REV(NORMAL/REVERSE)  
RESET RST

3. Press UP/DOWN button on the monitor to increase or decrease the value of the adjustment functions for optimum viewing.
4. VIDEO1 / VIDEO2 can use Menu Key to change, when power on.
5. The monitor will auto turn on, when gear happen.

## Accessories

Cable  
Remote Control Unit  
Stand  
User's Manual

