Soft Polyurethane Tubing


Series TUS



Suitable for piping in confined spaces
Extremely flexible
Soft polyurethane tubing

TUS related accessories Inner sleeve Series TJ

Reinforces soft polyuretharane tubing. Insert an inner sleeve into soft polyurethane tubing when used with a One-touch fitting.



Model	Applicable tubing model	Length	
TJ-0425	TUS0425	18	
TJ-0604	TUS0604	19	
TJ-0805	TUS0805	20.5	
TJ-1065	TUS1065	23	
TJ-1208	TUS1208	24	


Specifications

Material	C2700T (Electroless nickel plated)			
Wall thickness	0.2 mm			

A Precautions

Be sure to read before handling.
Refer to pages 15-18-3 to 4 for Safety Instructions and Common Precautions on the products mentioned in this catalog, and refer to pages 15-1-10 to 11 for Precautions on every series.

- Use a nylon or polyurethane tubing for general industrial water, otherwise the tube may result in being fallen out or bursted when the max. operating pressure is lower and the surge pressure is occurred.
- 2. The value of the max. operating pressure is at a temperature of 20°C. Refer to the burst pressure characteristics curve for other temperatures.
 - Furthermore, abnormal temperature rises caused by adiabatic compression may result in the burst of the tube.
- 3. The value of the minimum bending radius is measured at the temperature of 20°C. At higher temperatures, tubing could bend at a value greater than the minimum bending radius
- Use inner sleeve, taking the removing force into consideration when used with Onetouch fittings.



Fluid		Air					
Max. operating pressure at 20°C		0.6 MPa					
Burst pressure		Refer to the burst pressure characteristics curve.					
Applicable fitting		One-touch fitting, Insert tube fitting, Hose nipple (3)					
Min. bending radius (mm) (2)		8	15	15	22	29	
Operating temperature		-20 to +60°C (No freezing)					
Material		Polyurethane					
Tube drawing strength (N) (Using One-touch fitting)	Without inner sleeve	15	60	60	85	110	
	With inner sleeve	80	230	250	300	480	

Note 1) Not clear, but translucent due to material.


Note 2) Min. bending radius is measured as shown in the figure below.



Bend the tube into U-form at a temperature of 20°C. Fix one end and close loop gradually. Measure 2R when the tube breaks or is crushed.

Note 3) Always use inner sleeve (Series TJ) in safety circuit or critical area

Burst Pressure Characteristics Curve and Operating Pressure



How to Order

